


CAUTION

THIS ATV WAS SHIPPED WITHOUT ENGINE OIL. ALWAYS FILL WITH THE CORRECT AMOUNT AND GRADE OF ENGINE OIL AS LISTED IN THE OWNER'S MANUAL

ASSEMBLY/PRE-RIDE INSPECTION INSTRUCTIONS




FOR QUESTIONS ABOUT THESE ASSEMBLY INSTRUCTIONS, CALL COLEMAN POWERSPORTS 888-405-8725


A WARNING


NEVER ATTEMPT TO START THIS ATV WITHOUT READING AND UNDERSTANDING THE OWNER'S/ OPERATOR'S MANUAL. THE OWNER'S OPERATOR'S MANUAL PROVIDES INFORMATION ON SAFETY, PARTS, FUNCTIONS, PRE-RIDE INSPECTION, STARTING AND MAINTENANCE


REMOVAL FROM CRATE


ASSEMBLY INSTRUCTIONS ASSEMBLY FIRST RUCTIONS ASSEMBLY FIRST RUCTIONS














HANDLEBAR ASSEMBLY







STEP 1
Attach bottom clamp brackets to steering assembly bracket using M8 x 45 Bolts (4)



GEAR INDICATOR ASSEMBLY




Insert the gear indicator on the handlebars.



GEAR INDICATOR COVER



REAR WHEEL ASSEMBLY













M16 Castle Nuts

Hub Caps





Cotter Pins


NOTE


FILL TIRES WITH 10 PSI OF AIR BEFORE ASSEMBLY

STEP 1

Attach wheel in the following order:

- 1.).....Wheel
- 2.).....M16 Washer
- 3.).....M16 Caslte Nut
- 4.).....Cotter Pin






NOTE

Make sure tire tread faces forward and air valve stem is on the outside of the tire when installing.




STEP 2

Install Hub Caps on each wheel





FRONT WHEEL ASSEMBLY



PARTS







M14 Castle Nuts








NOTE


FILL TIRES WITH 10 PSI OF AIR BEFORE ASSEMBLY

STEP 1

Attach wheel in the following order:
1.).....Wheel

- 2.).....M14 Washer -
- 2.).....IVI14 VVasilei
- 3.).....M14 Caslte Nut
- 4.).....Cotter Pin






<u>NOTE</u>

Make sure tire tread faces forward and air valve stem is on the outside of the tire when installing.




STEP 2

Install Hub Çaps on each wheel





FRONT BUMPER ASSEMBLY




STEP 1

Install front bumper with M8 x 20 bolts and M8 x 12 bolt.





BATTERY ASSEMBLY



STEP 1


Install batter in battery bracket located underneath the seat of the ATV.

STEP 2

Attach the red wire to the POS + side of the battery with the provided screws.

Attach the black wire to the NEG - side of the battery with the provided screws.

NOTE: Make sure the the connections are tight.





PRE-RIDE INSPECTION

Inspecting and checking the condition of the ATV before each ride is important. Following the pre-ride check list will help ensure that you do not have mechanical problems which could result in injury or becoming stranded. Make sure the ATV is in good operating condition before each ride.

⚠ WARNING

Failing to inspect and maintain your ATV could be hazardous. Not following the pre-ride inspection procedures could result in loosing control of the ATV resulting in an accident, damage to the ATV, or injury. Always preform a pre-ride inspection before each ride.

⚠ WARNING


Preforming maintenance and checks while the engine is running could be hazardous.

You could be severely injured by moving parts or hot surfaces.

Never perform maintenance or check procedures while the engine is running with the exception of checking the ignition switch or throttle.

WHAT TO CHECK	CHECK FOR
Steering	Smoothness No restriction of movement Correct fluid level
	Inspect hoses for leaks Inspect brake pads for wear
Tires	Proper tire pressureProper tread depthRubber has no cracks
Fuel Tank	 Enough fuel for the ride Fuel cap secure Hoses have no signs of cracks or leaks
Throttle Pedal	 Pedal snaps back to idle when relased Operates freely
Engine Ignition Switch	Switch shuts off engine when activated
Engine Oil	Correct oil level
All Guards	No damageSecurely attached
Drive Chain	Proper tensionLubricatedNo excessive wear or damage
General Condition	 All nuts and bolts are tight No rattles from engine or frame while running





⚠ WARNING

NEVER ATTEMPT TO START THIS ATV WITHOUT READING AND UNDERSTANDING THE OWNER'S/ OPERATOR'S MANUAL. THE OWNER'S/ OPERATOR'S MANUAL PROVIDES INFORMATION ON SAFETY, PARTS, FUNCTIONS, PRE-RIDE INSPECTION, STARTING AND MAINTENANCE



(888) 405-8725 1775 E. University Dr., Tempe, AZ 85281 www.colemanpowersportsusa.com

www.facebook.com/colemanpowersportusa.com www.instagram.com/colemanpowersports usa





